MAINTENANCE TECHNICAL SUPPORT CENTER HEADQUARTERS MAINTENANCE OPERATIONS UNITED STATES POSTAL SERVICE



Maintenance Management Order

SUBJECT: Preventive, Predictive, and Operational

Maintenance Guidelines for Combined Input Output Sub-System (CIOSS) Using Electronic Conditioned

Based Maintenance (eCBM)

TO: All CIOSS Offices

DATE: September 15, 2016

NO: MMO-125-16

FILE CODE: 2CA

gmor:mm14121ad

		Online Change Record
Change #	Date	Description of Change
2	05/22/2020	Added the Infrared Thermography information after the online change record.
1	3/30/2018	Attachment 2, Task 39, Step added to check area around printer nozzle.

Infrared Thermography Information for DBCS Based Sorting Equipment – Plug and Receptacle Connectors is located at MTSC>HELPDESK>Service Portal>Knowledge Base>KB0013384.

This Maintenance Management Order (MMO) provides Preventive, Predictive, and Operational Maintenance Guidelines for the Combined Input Output Sub-System (CIOSS). This MMO **supersedes MMO-015-13**.

The method used to generate these maintenance tasks is WEB based through the Electronic Maintenance Activity Reporting and Scheduling system (eMARS) using the Electronic Conditioned Based Maintenance (eCBM) module.

The workhours indicated in the workload estimate (Attachment 1) reflect the *maximum* annual workhours required to maintain each system. Actual workhour requirements and the frequency of tasks are dependent on pieces processed to satisfy software counters that trigger the assignment of these tasks. Therefore, PM workhour requirements will vary day-to-day based on site specific machine utilization.

The minimum maintenance skill level required to perform each task is included in the Minimum Skill Level column of each checklist. This does not preclude higher level employees from performing any of this work.

Preventive Maintenance (PM) guidelines provide maintenance employees with the recommended task based maintenance activities. The Electronic Conditioned Based Maintenance (eCBM) is an abbreviated task list that represents a portion of the PM checklist. The complete master PM checklist must be accessible to all maintenance employees when performing PM and eCBM task based maintenance activities.

Web Access: http://mtsc.usps.gov

WARNING

Various products requiring Safety Data Sheets (SDS) may be utilized during the performance of the procedures in this bulletin. Ensure the current SDS for each product used is on file and available to all employees. When reordering such a product, it is suggested that current SDS be requested. Refer to SDS for appropriate personal protective equipment.

WARNING

The use of compressed or blown air is prohibited. An alternative cleaning method such as a HEPA filtered vacuum cleaner, a damp rag, lint-free cloth, or brush must be used in place of compressed or blown air.

WARNING

Steps contained in this bulletin may require the use of Electrical Work Plan (EWP) Personal Protective Equipment (PPE). Refer to the current EWP MMO for appropriate EWP PPE and barricade requirements.

Direct any questions or comments concerning this bulletin to the MTSC HelpDesk, online at https://tickets.mtsc.usps.gov/login.php or call (800) 366-4123.

Kevin Couch Manager

Maintenance Technical Support Center

HQ Maintenance Operations

Attachments: 1. Summary of Workload Estimate

2. Master Checklist: 03-CIOSS-AB-001-M: Power OFF/ON Tasks

3. Master Checklist: 09-CIOSS-AB-001-M: Operational Maintenance

ATTACHMENT 1

SUMMARY

WORKLOAD ESTIMATE

FOR

CIOSS SYSTEM

SUMMARY WORKLOAD ESTIMATE FOR CIOSS

Number of	mail pieces		SUMMARY	WORK LOAD ES	TIMATES FOR (CIOSS-AB				
Processed >	•	63,000,000	High end es	timate	For a 110 Stac	ker Machine				
Operation	Routine	Repair	Routine	Non- Productive Total		Operational Maintenance + Total Servicing				
Days	Servicing per	Time per	Servicing + Repair			1 Tour	2 Tours	3 Tours		
	Machine	Machine	Time	Machine	Machine	Hrs/Yr	Hrs/Yr	Hrs/Yr		
	(Hrs/Yr)	(Hrs/Yr) *	(Hrs/Yr)	(Hrs/Yr) **	(Hrs/Yr)	OpM x 1	OpM x 2	ОрМ х 3		
5 Days	1142.00	342.60	1484.60	148.46	1633.06	1,966.73	2,300.39	2,634.06		
6 Days	1323.13	396.94	1720.07	172.01	1892.08	2,292.48	2,692.88	3,093.28		
7 Days	1504.26	451.28	1955.54	195.55	2151.09	2,618.23	3,085.36	3,552.49		
*	Repair mai	ntenance estir	nates based o	on 30% of preve	ntive maintenan	ce.				
**	Based on 1	0% of total PN	I and repair.							
		THRESHOL	DS and PM T	IME SUMMARY	Hrs PER Year	OPERATION	AL MAINTEN	ANCE		
			Daily	1,267.93		77 MIN. PER	TOUR PER N	//ACHINE		
			Monthly	9.40		One Tour	Two Tours	Three Tours		
			0	0.00	5 Day	333.67	667.33	1001.00		
			0		,					
			1,100,000	0.00 19.09	6 Day	400.40	800.80	1201.20		
			1,200,000	126.00	7 Day	467.13	934.27	1401.40		
			2,200,000	20.05						
			4,800,000	57.53						
			14,300,000	1.47						
			15,600,000	3.97						
			20,000,000	12.08						
			62,400,000	2.25						

	Mach	ine Oper	ating 5 Day	ys/Week				
# of				Non-		Operational		ce + Total
Stackers	Routine	Repair	Routine	Productive	Total	; !	Servicing	1 1
	Servicing per	Time per	Servicing + Repair	Time per	Servicing per	1 Tour	2 Tours	3 Tours
	Machine	Machine (Hrs/Yr)	Time	Machine	Machine	Hrs/Yr	Hrs/Yr OpM x	Hrs/Yr OpM x
	(Hrs/Yr)	* *	(Hrs/Yr)	(Hrs/Yr) **	(Hrs/Yr)	OpM x 1	. 2	3
110	1142.00	342.60	1484.60	148.46	1633.06	1966.73	2300.39	2634.06
126	1161.42	348.43	1509.85	150.99	1660.84	1994.51	2328.17	2661.84
142	1176.38	352.91	1529.29	152.93	1682.22	2015.89	2349.55	2683.22
158	1191.38	357.41	1548.79	154.88	1703.67	2037.34	2371.00	2704.67
174	1206.35	361.91	1568.26	156.83	1725.09	2058.76	2392.42	2726.09
190	1225.84	367.75	1593.59	159.36	1752.95	2086.62	2420.28	2753.95
206	1240.78	372.24	1613.02	161.30	1774.32	2107.99	2441.65	2775.32
222	1255.82	376.75	1632.57	163.26	1795.83	2129.50	2463.16	2796.83
238	1266.45	379.94	1646.39	164.64	1811.03	2144.70	2478.36	2812.03
254	1289.99	387.00	1676.99	167.70	1844.69	2178.36	2512.02	2845.69
270	1304.94	391.48	1696.42	169.64	1866.06	2199.73	2533.39	2867.06
286	1319.94	395.98	1715.92	171.59	1887.51	2221.18	2554.84	2888.51
302	1334.90	400.47	1735.37	173.54	1908.91	2242.58	2576.24	2909.91

	Mach	ine Opera	ating 6 Day	ys/Week				
# of Stackers	Routine Servicing	Repair Time	Routine Servicing	Non- Productive	Total Servicing	Operational	Maintenand Servicing	ce + Total
	per	per	+ Repair	Time per	per	1 Tour	2 Tours	3 Tours
	Machine	Machine (Hrs/Yr)	Time	Machine	Machine	Hrs/Yr	Hrs/Yr OpM x	Hrs/Yr OpM x
	(Hrs/Yr)	*	(Hrs/Yr)	(Hrs/Yr) **	(Hrs/Yr)	OpM x 1	2	3
110	1323.13	396.94	1720.07	172.01	1892.08	2292.48	2692.88	3093.28
126	1344.29	403.29	1747.58	174.76	1922.34	2322.74	2723.14	3123.54
142	1360.11	408.03	1768.14	176.81	1944.95	2345.35	2745.75	3146.15
158	1375.98	412.79	1788.77	178.88	1967.65	2368.05	2768.45	3168.85
174	1391.82	417.55	1809.37	180.94	1990.31	2390.71	2791.11	3191.51
190	1413.04	423.91	1836.95	183.70	2020.65	2421.05	2821.45	3221.85
206	1428.85	428.66	1857.51	185.75	2043.26	2443.66	2844.06	3244.46
222	1444.75	433.43	1878.18	187.82	2066.00	2466.40	2866.80	3267.20
238	1456.25	436.88	1893.13	189.31	2082.44	2482.84	2883.24	3283.64
254	1481.52	444.46	1925.98	192.60	2118.58	2518.98	2919.38	3319.78
270	1497.34	449.20	1946.54	194.65	2141.19	2541.59	2941.99	3342.39
286	1513.21	453.96	1967.17	196.72	2163.89	2564.29	2964.69	3365.09
302	1529.03	458.71	1987.74	198.77	2186.51	2586.91	2987.31	3387.71

	Mach	ine Oper	ating 7 Day	ys/Week				
# of Stackers	Routine	Repair	Routine	Non- Productive	Total	Operational	Maintenand Servicing	ce + Total
	Servicing per	Time per	Servicing + Repair	Time per	Servicing per	1 Tour	2 Tours	3 Tours
	Machine	Machine (Hrs/Yr)	Time	Machine	Machine	Hrs/Yr	Hrs/Yr OpM x	Hrs/Yr OpM x
	(Hrs/Yr)	*	(Hrs/Yr)	(Hrs/Yr) **	(Hrs/Yr)	OpM x 1	2	3
110	1504.26	451.28	1955.54	195.55	2151.09	2618.22	3085.36	3552.49
126	1527.16	458.15	1985.31	198.53	2183.84	2650.97	3118.11	3585.24
142	1543.84	463.15	2006.99	200.70	2207.69	2674.82	3141.96	3609.09
158	1560.58	468.17	2028.75	202.88	2231.63	2698.76	3165.90	3633.03
174	1577.29	473.19	2050.48	205.05	2255.53	2722.66	3189.80	3656.93
190	1600.24	480.07	2080.31	208.03	2288.34	2755.47	3222.61	3689.74
206	1616.92	485.08	2102.00	210.20	2312.20	2779.33	3246.47	3713.60
222	1633.68	490.11	2123.79	212.38	2336.17	2803.30	3270.44	3737.57
238	1646.05	493.82	2139.87	213.99	2353.86	2820.99	3288.13	3755.26
254	1673.05	501.92	2174.97	217.50	2392.47	2859.60	3326.74	3793.87
270	1689.74	506.92	2196.66	219.67	2416.33	2883.46	3350.60	3817.73
286	1706.48	511.94	2218.42	221.84	2440.26	2907.39	3374.53	3841.66
302	1723.16	516.95	2240.11	224.01	2464.12	2931.25	3398.39	3865.52

Repair maintenance estimate	es based on	30.00%	of preventive maintenance.
	Based on	10.00%	of total PM and repair.

			Powe	r Off Tasl	KS			
	Threshold ->	3K	1.2M	2.2M	4.8M	4.8M	62.4M	
	Item # ->	5	9	10	30	31	32	
	110	9	37	37	71	21	70	
	126	1	5	3	10	3	10	
	142	2	10	6	20	6	20	
	158	3	15	9	30	9	30	
	174	4	20	12	40	12	40	
	190	5	25	15	50	15	52	
# Stackers	206	6	30	18	60	18	62	Minutes
Stackers	222	7	35	21	70	21	72	
	238	8	40	24	80	24	82	
	254	9	45	27	90	27	90	
	270	10	50	30	100	30	100	
	286	11	55	33	110	33	110	
	302	12	60	36	120	36	120	

		Pow	er On	Tasks			
	Threshold ->	Monthly	1K	1.2M	15.6M	20M	
	Item # ->	36	33	44	45	56	
	110	22	10	7	14	230	
	126	2	1	1	2	10	
	142	4	1	2	2	20	
	158	6	1	3	3	30	
	174	8	1	4	3	40	
,,	190	10	2	5	4	52	
# Stackers	206	12	2	6	4	62	Minutes
Stackers	222	14	2	7	5	72	
	238	16	2	8	5	82	
	254	18	3	9	6	90	
	270	20	3	10	6	100	
	286	22	3	11	7	110	
	302	24	3	12	7	120	

THIS PAGE BLANK

ATTACHMENT 2

CIOSS MASTER CHECKLIST

03-CIOSS-AB-001-M

POWER OFF AND POWER ON TASKS

U.S. Postal Service		IDENTIFICATION											
Maintenance Checklist	WORK CODE					CLASS CODE				NUMBER			TYPE
	0 3	СІ	0	S	S			Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equipmer	nt Model	·		·	Bulleti		name 4121		Occurr		СВМ	

Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	3
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
			Req	Lev	Hours	Fed	-
		<u>I</u>	(min)			(000)	
SAFETY STATEMENT	1.	COMPLY WITH ALL SAFETY PRECAUTIONS. Disconnect power and apply lockouts when required by this instruction. Refer to current	1	All			
		local lockout procedures to properly shut down and lock out this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any					
		further action on the equipment. THE USE OF COMPRESSED OR BLOWN AIR					
		IS PROHIBITED. When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner or a damp rag must be used in place of compressed or blown air. A lint-					
		free cloth or brush may be used on optical equipment only when other cleaning methods cannot be used. Report safety deficiencies to your supervisor immediately upon detection.					
		WARNING FOR EWP/PPE: Steps contained in this bulletin may require the use of Electrical Work Plan (EWP) Personal Protective Equipment (PPE). Refer to the current EWP MMO for appropriate EWP PPE and barricade requirements.					
CIOSS SYSTEM REPORTS	2.	Prior to performing the power down lockout procedures; generate, print, or view an End of Day Report and Tracking Report.	4	10		1	
		Analyze data provided on these reports to determine if any areas of machine are degraded or in need of attention.					
CIOSS SYSTEM SHUTDOWN	3.	Shut down the CIOSS System in accordance with the most recent documentation.	12	9		1	
PRINTERS AND COMPUTERS		Shut down the CIOSS System in accordance with the following references:					
		 ID-Tag and POSTNET Ink Jet Printers refer to the manufacturers manual Chapter 3 Imaje S7 Supra Postal User Guide (PSN 7610-07-000-5515, P/N 0250235). 					

U.S. Postal Service							IDE	IDENTIFICATION								
Maintenance Checklist	WORK CODE		EQUIPMENT ACRONYM							CLASS CODE			NUMBER			TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equi	ipmer	nt Mo	del				В	ulletin N		name 4121	(Occurr		СВМ	

Oystelli							
Part or	Item	Task Statement and Instruction	Est.	Min.	-	Thresholds	3
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
			Req	Lev	Hours	Fed	
			(min)			(000)	
		2. For detailed steps to properly shut down the					
		system refer to MS Handbook MS-252					
		Volume B, Section 5.3.					
		NOTE					
		If any problems are encountered while					
		performing these procedures report them					
		to your supervisor.					
CIOSS SYSTEM POWER DOWN	4.	Power down and lock out power.	1	ALL		1	
		WARNING					
		Electrical power will always be present					
		at the input of the disconnect device					
		unless the circuit is disabled at the					
		facility power distribution panel					
		located at					
		Power down the machine and lock out its					
		electrical power as prescribed by the current					
		local lockout instructions providing					
		lockout/restore procedures.					
CIOSS SYSTEM	5.	Mail search.	9	7		3	
MAIL SEARCH		1. Remove all machine panels, except for					
		diverter plate cover assemblies (Wimpy					
		panels) and stacker lower front panel					
		assemblies.					
		2. Ensure each of the cover's gas springs and					
		retaining clips are able to hold the cover in					
		the uppermost position. Report defective					
		components to the supervisor and/or create					
		a work order.					
		2					
		Search all base plate areas and module interiors for mail.					
		4. Remove any mail pieces found.					
		5. Remove any large amounts of debris while					
		doing this mail search to prevent clogging of					
		the vacuum when doing vacuuming tasks.					
		6. Follow local procedures for returning mail to					
		operations for processing.					
			<u></u>				

U.S. Postal Service								IDE	NTIF	CAT	ION					
Maintenance Checklist	_	WORK EQUIPMENT CODE ACRONYM					•			CLA CO	ASS DE	1	IUMB	ER	TYPE	
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System								В	ulletin N		name 4121		Occu	rence e	CBM	

System							
Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time Req (min)	Min. Skill Lev	Run Hours	Thresholds Pieces Fed (000)	Freq.
CIOSS SYSTEM VACUUM 1	6.	WARNING Edges of spiral stacking auger may be sharp. Use extreme caution when working near spiral-stacking auger. WARNING Use extreme caution in area of pocket assembly wear plate. On some machines, wear plate extends past edge of its base and into stacker area, exposing sharp edges. WARNING Discard solvent soaked materials according to local procedures to prevent pollution or spontaneous combustion. NOTE While performing this task, check for loose, cracked, or damaged hinges in Reader Module. Notify supervisor if problem found. Refer to the most recent MMO, currently MMO-077-03, dealing with this problem. http://mtsc.usps.gov/bulletins.cfm Vacuum and clean internal and base-plate areas of the machine starting at the front of stacker module #1, and proceed toward the feeder and around the machine to end up and include the rear of stacker module #1. In the process of doing this, ensure the following areas are cleaned: 1. The P-SEN10 and P-LED10 assemblies. 2. Feeder section two power supplies (exterior cage). 3. Outside surfaces of jogger assembly. 4. Exterior of monitor, keyboard, printer, and printer stand.		7		60	

U.S. Postal Service								IDE	NTIFIC	ATI	ON					
Maintenance Checklist	WC CO	RK DE			_		MENT NYM	•			CLA CO		N	UMBE	ĒR	TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equ	ipmer	nt Mo								name 4121		Occurr		СВМ	

System							
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	3
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
			Req (min)	Lev	Hours	Fed (000)	
		I	()			(000)	
		5. Engure leger printer has an adequate amount					
		5. Ensure laser printer has an adequate amount of paper for three tours of operation, add					
		paper if necessary by following instructions in					
		most current MS-229.					
		http://mtsc.usps.gov/msbooks/					
		a. Open paper tray.					
		b. Fill paper tray with paper.					
		c. Close paper tray.					
		6. Reader Module 5v power supply and light					
		barriers.					
		7. Exterior of the IPC and the WFOV					
		Processor.					
		2 - 11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1					
		8. Tray label printers cleaning and label stock					
		loading.					
		a. Clean/vacuum interior and exterior of					
		label printers, located on first and eighth					
		stacker modules.					
		b. Ensure label printers are loaded with a					
		sufficient supply of label material to					
		support three tours of operation. If					
		required, load the label printer:					
		1) Insert label stock between guides					
		Insert label stock between guides into back of label printer.					
		·					
		Place wide end of label stock into					
		label printer first, face down.					
		3) Push print head lever back.					
		, .					
		Push label stock through until it comes out front of label printer.					
		•					
CIOSS SYSTEM	7.	Ensure the cleaning of the following filters	20	7		150]
VACUUM		are done:					
FILTERS		1. Transport module: The two inlet filters on the					
		air pump.					
		2. Drying turn module: The three Variable					
		Frequency Drive (VFD) filters.					
		OCR/Tag Printer module:					
		•					
		a. Air filters in door in front of CM card					
		cage.					
	<u> </u>				1	1	1

U.S. Postal Service							IDE	ENTIFICAT	ION					
Maintenance Checklist	WORK CODE					MEN ⁻ NYM				ASS DE	Ν	UMBE	ĒR	TYPE
	0 3	С	I	0	S	S			Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equipme								name 4121	(Occurr		CBM	

	1		7 1 0 1 1 1 1 1 1 1	1 - :				
Part or Component	Item No		Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill	Run	Thresholds Pieces	Freq.
Обтропоп			(Comply Will all Callott Salety procautions)	Req	Lev	Hours	Fed	i ieq.
<u> </u>	<u> </u>			(min)	<u> </u>		(000)	
			b. Filter on the ICS reader electronics unit.					
			c. Air pump inlet filter for IJP.					
		4.	HSLA module:					
			a. Four rear door filters.					
			b. Filter on ICS reader.					
			c. Two inlet filters on air pump for Doubles Detector.					
			d. Vacuum the two filters located on the back of the PostJet HSLP Controller.					
			e. Vacuum the filter located on the top of the HSLP Print Engine.					
		5.	Drying Transport module: Filters on ICS reader electronics unit.					
		6.	Leveler module: Three Variable Frequency Drive (VFD) filters.					
		7.	Reader module: WFOV and IPC computer filters.					
		8.	Computer system component air filters cleaning.					
			At front of computer cabinet, loosen thumbscrews on following components filter grills:					
			1) Host computer.					
			2) OCR computer.					
			3) VPC.					
			4) VPC2.					
			5) IS computer.					
			b. Remove each filter grill and filter material.					
			c. Clean each filter grill and filter material.					
			d. Re-install the filter material and filter grill.					
			e. Tighten thumbscrews.					
CIOSS SYSTEM: COMPUTER	8.	Cle filte	an and wash computer cabinet and IPC	22	7		1200	
SYSTEMS FILTER WASHING		1.	Vacuum and wash IPC filter. Vacuum filter located on IPC computer. Remove and					

U.S. Postal Service								IDE	NTIFIC	CAT	ON						
Maintenance Checklist	_	DRK DDE					MENT DNYM	•				ASS DE		NUN	ЛВE	R	TYPE
	0	3	С	I	0	S	S				Α	В	0		0	1	М
Equipment Nomenclature	Equ	ipmer	nt Mo	del				Вι	ılletin	Filer	name		Оссі	rren	се		
Combined Input Output Sub-							M	M1	4121				еC	CBM			
System																	

System							
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	S
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
			Req (min)	Lev	Hours	Fed (000)	
			(111111)		ļ	(000)	
		wash, in warm water, filter located on					
		computer assembly.					
		IS computer filter cleaning.					
		,					
		Vacuum filter located on IS computer. Pull gently on rear corner of square filter					
		holder to remove it.					
		b. Remove and wash, in warm water, filter					
		located on IS computer assembly.					
		•					
		 c. Allow filter to dry, then reassemble and reinstall filter assembly. 					
		·					
		3. VPC, VPC1, OCR, and Host computer filter					
		cleaning.					
		a. Remove and vacuum four filters located					
		in computer cabinet on weekly basis. Pull gently on rear corner of square filter					
		holder to remove it.					
		b. Remove filters and wash in warm water.					
		c. Allow filters to dry, and then reassemble					
		and reinstall filter assembly.					
CIOSS SYSTEM	9.	Clean stacker modules 2 through to the end	37	7		1200	
VACUUM 3		module by vacuuming; remove dust and debris as follows:					
		WARNING					
		Edges of spiral stacking auger may be					
		sharp. Use extreme caution when					
		working near spiral-stacking auger.					
		WARNING					
		Use extreme caution in area of pocket					
		assembly wear plate. On some machines, wear plate extends past					
		edge of its base and into stacker area,					
		exposing sharp edges.					
		WARNING					
		Discard solvent soaked materials according to local procedures to					
		prevent pollution or spontaneous					
		combustion.					
					<u> </u>	<u> </u>	

U.S. Postal Service								IDE	NTIFI	CATI	ON					
Maintenance Checklist		WORK EQUIPMENT CODE ACRONYM						•			CL/ CO	ASS DE		MUV	BER	TYPE
	0	3	С	I	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System								В	ulletin M		name 4121		Occu		e CBM	1

Part or	Item	Task Statement and Instruction	Est.	Min.		Threshold	S
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
		Clean stacker modules #2 through End Module, transport area, interior, and pocket assemblies, including light barriers. This does not include the Wimpy Panels. Engure light barriers are clean.					
		 Ensure light barriers are clean. Do the following to clean filters associated 					
		with the PostJet HSLP: a. Using vacuum cleaner, vacuum fan filter on back side of PostJet Print Station.					
		 b. Check fan filter on back of Print Station. Create work order if replacement is required. 					
		 c. Check fan filters on back of Controller. Create work order if replacement is required. 					
CIOSS SYSTEM	10.	Check belts and rollers.	37	9		2200	
BELTS AND ROLLERS		Starting at the front of stacker module #1, proceed toward the feeder and around the machine to end up and include the rear of stacker module #1. Then proceed down the back of the stacker modules and around to the front of the stacker modules.					
		 Check all belts (drive and letter transport) for indications of wear. Replace worn, deformed, split, or torn belts. 					
		2. Check for broken or burred gate flags.					
		 Write work orders as needed for replacement of belts and/or gates. 					
		 Check all rollers (drive and idler) for proper adjustment, dirt build-up, and indications of wear. Replace rollers as necessary. 					
		5. In the Reader Module clean the motor power unit filter.					
		Write work orders as needed for adjustments, cleaning, and/or replacement of rollers.					
CIOSS SYSTEM	11.	Foam roller checks.	3	9		4800	
FOAM ROLLERS		Check WFOV foam roller in the OCR/Tag printer module. Replace roller if necessary.					

U.S. Postal Service								IDE	NTIFI	CAT	ION					
Maintenance Checklist	_	WORK EQUIPMENT CODE ACRONYM					•			CLA CO	ASS DE	1	NUMB	ER	TYPE	
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System								В	ulletin N		name 4121		Occu	rence e	CBM	

System							
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	3
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
		Check the foam rollers in the HSLA module.					1
		Replace the roller/s if necessary.					
		Check the WFOV foam roller in the Reader Module. Replace the roller if necessary.					
CIOSS SYSTEM SAFETY	12.	Verification of safety warning labels.	2	7		4800	
WARNING		NOTE					
LABELS		Refer to the most recent MMO dealing with safety warning labels; currently, this is MMO-056-09, for label locations and part numbers. http://mtsc.usps.gov/bulletins.cfm					
		 Verify feeder modules have safety warning labels present, correctly located and in good condition. 					
		Verify stacker modules have safety warning labels present, correctly located and in good condition.					
		 Notify supervisor of missing or worn feeder/stacker safety warning labels and initiate a work order to replace or remove and replace as necessary. 					
CIOSS SYSTEM: ENCODERS	13.	Replace Encoder (Tachometer) Tube Coupler and Hose Clamp.	40	9		15600	
		NOTE					
		There are two types of Hose Couplers: The 7/32 ID by 1.269 inches in length, which is PSN 4720-02-000-4060, and the Hose Coupler, that is 39 mm with PSN 4730-10-000-5863; consult your most current MS Manual Illustrated Parts Breakdown on the MTSC web site to be certain which to use.					
		 Remove and replace the Encoder Tube Coupler and Hose Clamp located on the Drying Turn Module, Label Printer Base Plate, Drying Turn Transport Module, and Reader Module Plate. 					
		2. The date this document was written the					

U.S. Postal Service								IDE	NTIFI	CATI	ON					
Maintenance Checklist		WORK EQUIPMENT CODE ACRONYM					•			CLA CO		N	UMBE	ER	TYPE	
	0	3	С	-	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System						В	ulletin N		name 4121	(Occurr		СВМ			

Davit	14	Tools Obstancent and Instruction	F	N 4! · ·		Thusalist	
Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill	Run	Thresholds Pieces	Freq.
оотрологи	NO	(comply with all current salety precautions)	Req (min)	Lev	Hours	Fed (000)	гтец.
		following references in the MS-252 parts volume applied:					
		a. Drying Turn Module – Fig 6-5, items 6 & 7					
		b. Label Printer Baseplate – Fig 10-29, items 8 & 9					
		c. Drying Transport Module – Fig. 12-10, items 3 & 4					
		d. Reader Module – Fig 14-62, items 16 & 17					
		 If problems occur while doing these procedures notify your supervisor and if needed generate a work order to resolve those problems. 					
CIOSS SYSTEM	14.	Check for mail under machine.	64	7		62400	
UNDER MACHINE CLEANING		Remove foam strips from back side of machine and outer side of Feeder, Transport Section, and Tag scanner.					
		Using a flashlight, start at transport, and look for mail pieces under machine, proceed to check for mail to last stacker.					
		3. Remove any mail pieces found.					
		Follow local procedures for returning mail to operations for processing.					
		Clean under machine.					
		Clean/vacuum any dust and debris found from under machine, recommend start at backside of last stacker and work back to transport and feeder.					
		Re-install foam strips to backside of machine.					
READER	15.	Reader Module cleaning.	10	7		180	
MODULE ICS AND WFOV		 Clean the ICS read head and associated reflector. Recommended cleaner is Riptide, PSN 6850-01-394-0164, and P/N RIP-TIDE- BX4EA. 					
		Clean WFOV camera lens and lamp assemblies as follows:					

U.S. Postal Service								IDE	NTIFI	CATI	ON					
Maintenance Checklist		WORK EQUIPMENT CODE ACRONYM								CLA CO		N	UMBE	ER	TYPE	
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System						В	ulletin N		name 4121	(Occurr		СВМ			

Combined Input Output Su System	1b-	MM14121			eCBM	
Part or Item Component No	Task Statement and Instruction (Comply with all current safety precaution	Est. Time Req (min)	Min. Skill Lev	Run Hours	Thresholds Pieces Fed (000)	Freq.
	removing the Aperture/Illumina assembly. Cleaning or checks sho occur only after immediate area is of mail dust. a. Remove WFOV LED Aperture/ Illumination assembly by loosening thumbscrew and pulling unit up. b. Visually check the aperture plates sapphire glass for foreign objects c. Remove dust on the exterior of sapphire glass using dry cotton If adhesive build-up is on the siglass, remove it with a sof dampened with a site-approved complete to the comp	ea is effore ation ould clear swabs. sapphire ft cloth cleaner. s or of mera air n LED optical re brush the slot				
	in the Aperture/Illumination as while keeping brush or cleaning pressed to sapphire glass to remodust. f. Replace LED assembly and tighted thumbscrew.	ssembly g media ove any				

U.S. Postal Service								IDE	NTIFI	CATI	ON					
Maintenance Checklist		WORK EQUIPMENT CODE ACRONYM					•			CLA CO		N	UMBE	ER	TYPE	
	0	3	С	-	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System						В	ulletin N		name 4121	(Occurr		СВМ			

Part or	Item	Task Statement and Instruction	Est.	Min.		Threshold	
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
		Vacuum/clean dust and debris from Reader Module.					
READER MODULE ICS AND WFOV	15.5.	Vacuum/clean top of Reader Module.	5	7			Month
READER MODULE	16.	Clean WFOV and IPC assemblies. Clean WFOV and IPC assemblies as follows:	15	10		4800	
COMPUTERS		1. Slide out WFOV processor slide shelf.					
		2. Remove cover from WFOV processor.					
		3. Clean assembly interior, using vacuum cleaner.					
		4. Replace cover.					
		5. Slide WFOV processor slide shelf back.					
		6. Repeat process for IPC computer.					
ADDRESS	17.	Address Printer service.	6	9			Week
PRINTER MODULE: FILTERS		 Engage red shipping clip on the left side of the Print Station as you look at it from the front. 					
		 Disconnect the three electrical connectors from the Print Station, (Encoder X4, Data X32, and Power X33). 					
		3. Remove the two nuts, lock, and flat washers securing the Print Station to the base plate.					
		4. Leave the ink line connected but exercise care so as not to kink the line. This will prevent dirt and dust from contaminating the ink system.					
		 Lift the Print Station from the operational position and place it on the CIOSS deck plate so the front faceplate is accessible. 					
		6. Remove six 2.5mm screws securing the faceplate to the print station.					
		7. Remove faceplate.					
		8. Inspect inside floor of Print Station. If ink or dirt buildup is visible, use lint free wipe (PSN 5836-13-000-7200) and with extreme caution remove any dirt or ink build up.					
		Verify that no internal connectors were dislodged during the cleaning process.					

U.S. Postal Service								IDE	NTIFI	CAT	ON						
Maintenance Checklist		WORK EQUIPMENT CODE ACRONYM					•			CL/ CO			NUI	MBE	R	TYPE	
	0	3	С	ı	0	S	S				Α	В	C)	0	1	М
Equipment Nomenclature Combined Input Output Sub-	Equipment Model						Вι	ulletin M		name 4121		Occı	ırreı		свм		
System							IVI	IIVI I	7121				-	וויוטכ			

Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	3
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
			Req (min)	Lev	Hours	Fed (000)	
	· ·	·	/		T	1	
		10. Using a lint free wipe (PSN 5836-13-000-7200) only, clean both sides of the faceplate.					
		11. Reinstall the faceplate and start all six screws before tightening any of them. Slightly tighten each screw a little at a time until all are secure. The two screws near the nozzle plate should be the first ones to tighten. Using this technique will ensure the faceplate will self-align.					
		12. Place the Print Station back on its mounting bolts.					
		13. Install the flat washers, lock washers, and nuts, and secure them.					
		14. Reinstall connectors removed in step 2.					
		15. Ensure ink line is not kinked.					
		Disengage red shipping clip on left side of the print station.					
(HSLA) MODULE:	18.	Clean the OSR (ICS3) read head and	1	7		173	
OTHER SIDE ID		associated reflector:					
TAG READER		Recommended cleaner is Riptide, PSN 6850-01-394-0164, P/N RIP-TIDE-BX4EA 4.					
HIGH SPEED	19.	Clean the Double Detector Glass Window.	1	7		180	
LABEL APPLICATOR (HSLA) MODULE DOUBLES DETECTOR		Using lens paper or optics brush, clean the Doubles Detector glass window. The window is accessed via the rectangular opening in the side of the unit.					
HIGH SPEED	20.	Check and clean HSLA1 and HSLA2.	10	7		180	
LABEL APPLICATOR		CAUTION					
(HSLA) MODULE		Do not use strong, caustic, or solvent-					
ČLEAŃING HSLA 1 & 2		based liquids for cleaning HSLA. Do not apply a liquid directly on machine. Apply liquid to cleaning cloth, and then use the cloth to clean HSLA. Failure to comply may result in damage to HSLA. 1. Check and clean HSLA 1 and HSLA 2 as follows.					
		Unlock and pull the HSLA application slide outward to its service position.					

U.S. Postal Service						IDE	ENTIFI	CATI	ON						
Maintenance Checklist	WORK CODE	CODE ACRONYM								ASS DE		Νl	JMBE	ĒR	TYPE
	0 3	CI	0	S	S				Α	В		0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equipmer	nt Model				В	Bulletin I V		name 4121		Oc	curr	ence e(СВМ	

Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	3
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
			Req (min)	Lev	Hours	Fed (000)	
	1		('''''')			(000)	
		b. Remove label material from HSLA if not					
		previously removed.					
		2. Remove the guiding and shaping area cover					
		plate, located at the vacuum/guide-shaping					
		areas, and clean as required.					
		3. Using Simple Green, or equivalent, clean					
		any glue and /or dust from guiding and					
		shaping unit.					
		4. Replace the guiding and shaping area cover					
		plate when completed.					
		5. Using Simple Green, or equivalent, clean					
		any glue and/or dust from the surface of the					
		applicator drum.					
		a. Loosen the two captive screws securing					
		the application head to the cutter unit					
		using a 5 mm hex key.					
		b. Raise application head until it reaches					
		its stop limit, and place in service					
		position.					
		WARNING					
		When checking the moving and					
		stationary be cautious of sharp blades edges.					
		c. Check moving and stationary blades for					
		damage, debris, and adhesive build-up.					
		Take corrective action as needed.					
		d. Ensure cutter unit area is free of label					
		material slivers and adhesive build-up.					
		e. Rotate or replace moving blade as					
		required in accordance with MS-227,					
		Vol. A.					
HIGH SPEED	21.	Clean the vacuum turbine control unit filters.	18	7		1200	
LABEL		Unlock and open the 2 front doors in the					
APPLICATOR		module immediately to the left of the HSLAs.					
(HSLA) MODULE		·					
TURBINE FILTERS		 Locate air filter grills on both sides of control units for 2 vacuum turbine assemblies. 					
ILIENS							
		3. Remove (Unsnap) the 4 air filter grills.					
		4. Remove air filter elements from air filter					
		grills.					
	ıl				1		

U.S. Postal Service								IDE	NTIFIC	ATI	ON					
Maintenance Checklist		WORK EQUIPMENT CODE ACRONYM					•			CLA CO		N	UMBE	ĒR	TYPE	
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System					В	ulletin F M I		name 4121		Occurr		СВМ				

System							
Part or	Item	Task Statement and Instruction	Est.	Min.		Threshold	
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
			,			(333)	
		Wash the air filter elements in clean, warm, soapy water.					
		Thoroughly rinse the air filter elements in clean water.					
		7. Blot the air filter elements in paper towels to remove as much moisture as possible.					
		8. Air dry filter elements.					
		9. Put an air filter element into left air filter grill with blue surface of air filter element oriented toward exterior of the control unit. Put an air filter element into right air filter grills with the white surface of the air filter element oriented toward the exterior of the control unit. Snap air filter grills in place directly adjacent to fan on each side of control units.					
		10. Repeat steps 2 thru 9 with the remaining vacuum turbine control unit.					
HIGH SPEED	22.	Vacuum pump cleaning and servicing.	5	7			Week
LABEL APPLICATOR (HSLA) MODULE VACUUM PUMP CLEANING		Locate the two vacuum turbines. Open the vacuum turbine air filter assemblies. Clean the vacuum turbine air intake assembly and the air filters. Replace filters as necessary.					
CLLAINING		Close vacuum turbine air filter assemblies.					
		Close and lock the front door.					
OCR/TAG	23.	OCR/Tag Printer module cleaning.	13	7		180	
PRINTER MODULE ICS, WFOV/OCR, ID TAG PRINTER		 Clean the ICS read head and associated reflector. Recommended cleaner is Riptide, PSN 6850-01-394-0164, and P/N RIP-TIDE- BX4EA. 					
		Clean WFOV camera lens and lamp assemblies as follows:					
		WARNING					
		Use caution when working around WFOV aperture. Edges of aperture may become extremely sharp during machine use.					

U.S. Postal Service								IDE	ENTIF	ICAT	ION						
Maintenance Checklist		ORK ODE			_		NEMP NYNC	-				ASS DE		Νl	JMBE	R	TYPE
	0	3	С	1	0	S	S				Α	В		0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equ	ıipme	nt Mo	del				E	Bulletir N		name 4121		Oc	curr	ence eC	СВМ	

System							
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
		CAUTION					
		Ensure surrounding transport area is free of dust and debris before removing the Aperture/Illumination assembly. Cleaning or checks should occur only after the immediate area is clear of mail dust.					
		Remove WFOV LED Aperture/ Illumination assembly by loosening thumbscrew and pulling unit up.					
		 Visually check the aperture plates and sapphire glass for foreign objects. 					
		CAUTION					
		Do not contact the camera LED arrays or diffuser when cleaning the inside of the sapphire glass.					
		c. Remove dust on the exterior of camera sapphire glass, using dry cotton swabs. If adhesive build-up is on sapphire glass, remove it with a soft cloth dampened with a site-approved cleaner.					
		 d. Clean dust from inside WFOV camera LED assembly with a lens brush or air syringe. 					
		e. Clean dirt or streaks from LED assembly, using a lens brush or optical lens cleaning kit. Carefully, move brush or cleaning media straight down slot in Aperture/Illumination assembly while keeping brush or cleaning media pressed to the sapphire glass to remove any dust.					
		 Replace LED assembly and tighten thumbscrew. 					
		WARNING					
		When disposing of ink or ink-saturated waste in following steps, refer to procedures outlined in Safety Data Sheets (SDS). Eye protection (goggles or face shield) must be worn when					

U.S. Postal Service						IDE	ENTIFI	CATI	ON						
Maintenance Checklist	WORK CODE				MENT MYNC					ASS DE		Νl	JMBE	ĒR	TYPE
	0 3	С	0	S	S				Α	В		0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equipmer	nt Mode			·	E	Bulletin V		name 4121		Occ	curr	ence e(СВМ	

System	atput out							
Part or	Item		Task Statement and Instruction	Est.	Min.		Thresholds	s
Component	No		(Comply with all current safety precautions)	Time Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
			ning away contaminants using eup ink.					
			WARNING					
		head serve blow mead impli pape Othe	Imaje Ink Jet Printer (IJP) print d must be dried as a part of its ice. Do not use compressed or air. Appropriate, alternate ns of drying head must be emented and may include use of er towels or use of vacuum suction. er, equally effective methods may etermined locally.					
		area	extreme care in charge tunnel . Do not touch or bump charge area during checks or cleaning.					
			an the Imaje ID Tag printer print head guide plate (fence) as follows:					
		a.	Lift fence off its mounting studs.					
		b.	Remove print head from deck plate mount.					
		C.	Install print head onto service mount, and place service tray directly below it.					
		d.	Clean base plate of any ink, using towe and cleaning solution or replenished fluid.	el				
		e.	Clean fence using a towel and cleaning solution or replenished fluid.	g				
		f.	Clean up any spilled or splattered ink.					
		g.	Remove print head cover and check print head assembly for traces of ink.					
		h.	Clean print head as required accordance with Imaje S7 Supra Pos User Guide (PSN 7610-07-000-551 P/N 0250235), Chapter 3, Page 3-Paragraph A.	15,				
		i.	Replace print head cover and re-install print head onto deck plate mount.	ı				

U.S. Postal Service							IDE	ENTIFICAT	ION					
Maintenance Checklist	WORK CODE					MEN ⁻ NYM				ASS DE	Ν	UMBE	ĒR	TYPE
	0 3	С	I	0	S	S			Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equipme	nt Mod	del				E	Bulletin File MM1	name 4121	(Occurr		CBM	

Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
		j. Re-install fence on mounting studs.					
		Ink jet printer fluid replenishment.					
		NOTE					
		Do not use expired ink.					
		NOTE					
		Retain empty Imaje cartridges. Empty cartridges are required for draining and flushing Imaje printers.					
		Check and replenish (if necessary) Imaje ID Tag printer fluid bottles.					
		b. Remove and retain ink or make-up ink cartridge if empty.					
		NOTE					
		Cartridge holder is common to both ink and replenished fluid. Ink and replenisher fluid cartridge holders are located on the right side of printer. The ink cartridge holder is towards the front and the replenisher fluid cartridge holder is installed towards the back of printer.					
		Insert new bottle of ink or make-up ink into cartridge holder.					
		2) Install new cartridge holder.					
		c. Clean up any spilled or splattered ink.					
FEEDER MODULE	24.	Check feeder wear items as follows:	1	9		173	
HARDWARE		1. Teflon strip.					
		2. Rubber strippers.					
		3. Pick-off belts.					
		4. Compensator Levers.					
		 Generate a Work Order to replace as required. Refer to the most recent Maintenance Management Order covering feeder alignment and performance adjustments. 					

U.S. Postal Service								IDE	NTIFI	CAT	ION					
Maintenance Checklist	_	RK DE					MENT MYMC	•			CLA CO	ASS DE	1	NUMB	ER	TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equ	ipmer	nt Mo	del				В	ulletin N		name 4121		Occu	rence e	CBM	

· ·		<u> </u>					
Part or	Item	Task Statement and Instruction	Est.	Min.	Т	hresholds	;
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
			Req (min)	Lev	Hours	Fed (000)	
EEEDED MODULE	0.5	Observation of the state of the	45	-		4400	
FEEDER MODULE ALIGNMENT	25.	Check Feeder alignment.	15	7		1100	
CHECK		Check Feeder alignment (those steps that do not require power) using template, PSN 5220-04-					
		000-5005, and in accordance with the most					
		recent Maintenance Management Order,					
		currently MMO-029-08, covering Feeder alignment and performance adjustments.					
		NOTE					
		If any discrepancies are found, write a					
		work order to do a full Feeder alignment in accordance with the most recent MMO,					
		currently MMO-029-08, covering Feeder					
		alignment and performance adjustments.					
FEEDER	26.	Check Feeder transport for wear.	5	9		1100	
MODULE: MAIL TRANSPORT		1. Remove bottom feeder panel (clean). Check					
HARDWARE		transport belt for splits, tears, and deformity. Check drive chain for stretch, sprockets for					
		broken teeth and sprocket teeth wear. If					
		chain needs lubrication, refer to DBCS					
		maintenance handbook at completion of this route.					
		Check transport blade, transport blade					
		mounting bracket, and sliding bearing block					
		for loose bolts.					
		3. Check transport blade assembly for bearing					
		wear. Ensure transport assembly moves					
		smoothly along guide rod.					
		Check pawl for wear.					
FEEDER MODULE REPORT	27.	Report printer cleaning and paper check.	2	7		1200	
PRINTER		Clean report printer using a vacuum cleaner.					
		2. Ensure there is a sufficient amount of paper					
		to support at least three tours of operation; add paper as necessary.					
LEVELER	28.	Leveler module cleaning, checks, and fluid	15	7		200	
MODULE		replacement.	. •				
BASE PLATE AMD		1. Clean the Imaje POSTNET bar code printer					
IIVIAJE FRIIVIER		print head and guide plate (fence) as follows:					

U.S. Postal Service								IDE	NTIF	ICATI	ION					
Maintenance Checklist		RK DE			_		MEN NYN	-			CLA CO	ASS DE	N	JMBE	ĒR	TYPE
	0	3	O	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equ	ipmer	nt Mo	del				В	ulletir N		name 4121	C	ccurr		СВМ	

U.S. Postal Service								IDE	NTIFI	CATI	ON					
Maintenance Checklist		RK DE			_		MENT NYM				CLA CO		N	UMBE	ER	TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equi	ipmer	nt Mo	del				В	ulletin N		name 4121	(Occurr		СВМ	

System							
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	3
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
			Req (min)	Lev	Hours	Fed (000)	
		g. Replace print head cover and re-install					
		g. Replace print head cover and re-install print head onto deck plate mount.					
		h. Re-install fence on mounting studs.					
		2. Ink jet printer fluid replenishment.					
		Check and replenish Imaje POSTNET printer fluid bottles.					
		NOTE					
		Do not use expired ink.					
		NOTE					
		Retain empty Imaje cartridges. Empty cartridges are required for draining and flushing Imaje printers.					
		Remove and retain ink or make up ink cartridge if empty.					
		NOTE					
		Cartridge holder is common to both ink and replenisher fluid. Ink and replenisher fluid cartridge holders are located on the right side of printer. The ink cartridge holder is towards the front and replenisher fluid cartridge holder is installed towards the back of printer.					
		Insert new bottle of ink or make-up ink into cartridge holder.					
		d. Install new cartridge holder.					
		e. Clean up any spilled or splattered ink.					
STACKER MODULE	29.	Tray label printers cleaning and label stock loading.	2	7		180	
LABEL PRINTERS		Clean interior and exterior of label printers,					
		located on first and eighth stacker modules. 2. Ensure label printers are loaded with a sufficient supply of label material to support three tours of operation. If required, load the label printer:					
		Insert label stock between guides into back of label printer.					
		Place wide end of label stock into label printer first, face down.					

U.S. Postal Service								IDE	NTIF	CAT	ION					
Maintenance Checklist	_	RK DE					MENT MYMC	•			CLA CO	ASS DE	1	IUMB	ER	TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equ	ipmer	nt Mo	del				В	ulletin N		name 4121		Occu	rence e	CBM	

System							
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	S
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
		c. Push print head lever back.					
		 d. Push label stock through until it comes out front of label printer. 					
STACKER	30.	Stacker module cleaning.	71	7		4800	
MODULE GENERAL HARDWARE		 Open covers and remove panels. In the Stacker section, open or remove all machine panels, this includes diverter plate cover assemblies (Wimpy panels) and stacker lower front panel assemblies. 					
		 Clean stacker module. Clean all plates, covers, doors, framework, stacker display panels back and front side, etc. Do a visual check of wiring harnesses, cabling, and connector for wear, loose connections, etc., while cleaning. 					
STACKER MODULE GENERAL HARDWARE	30.5.	Vacuum/clean top of stacker modules.	20	7			Month
STACKER MODULE POWER	31.	Power supply cleaning. WARNING	21	9		4800	
SUPPLIES		Use non-metallic ends on the vacuum while cleaning the power supplies.					
		Remove the covers on the power supplies located in each stacker module.					
		 Using an approved vacuum cleaner, clean the inside of each power supply assembly. 					
		3. Install the covers.					
STACKER MODULES: FOAM PADS	32.	Check the Foam Pads located on every Guard Finger of the Stacker Fence Assembly in each Stacker Pocket area all Tiers.	70	9		62400	
		NOTE					
		For a location reference use MS-229, Vol E, Figure 11-10, Tier 1 Fence Assembly, Index Number 38. This reference was valid as of the date of this writing, as always use the most recent documentation available.					

U.S. Postal Service								IDE	NTIFIC	ATI	ON					
Maintenance Checklist	WC CO	RK DE			_		MENT NYM	•			CLA CO		N	UMBE	ĒR	TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equ	ipmer	nt Mo	del				В	ulletin F M I		name 4121		Occurr		СВМ	

					l.		
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	:
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
		(**************************************	Req	Lev	Hours	Fed	1104.
			(min)			(000)	
			1	1		1	1
		1. Check the Foam Pads (PSN 9320-03-000-					
		0023) to see if they are missing, damaged,					
		and/or degraded in any way.					
		and/or degraded in any way.					
		2. Make a list of the Foam Pads needing					
		replacement and their locations.					
		2 Congrete a Work Order to replace the Foom					
		3. Generate a Work Order to replace the Foam					
		Pads found and recorded in Steps 1 and 2 of					
		this instruction.					
01000 0107514	00		40	_			
CIOSS SYSTEM	33.	System power up.	10	7		1	
RESTORE		WARNING					
POWER		WARNING					
		Be cautious when working around or					
		on equipment when power has been					
		applied. Some of the following tasks					
		require that the machine be running.					
		Take precautions to prevent hair,					
		clothing, tools, and test equipment					
		from being caught in moving parts.					
		nom being caught in moving parts.					
		1. Power up preparation.					
		a. Ensure tools and materials are removed					
		a. Ensure tools and materials are removed from work area.					
		b. Replace all machine panels.					
		c. Close all machine doors and covers.					
		2. Restore power to equipment. Restore					
		power as prescribed by the current local					
		procedures providing lockout/restore					
		procedures and procedures as outlined in					
		MS-252, Vol B, Section 5.10, Steps 1-5.					
CIOSS SYSTEM	34.	Power on computer systems and IJP.	12	10		1	
COMPUTERS							
AND PRINTERS		WADNING					
		WARNING					
		Be cautious when working around or					
		on equipment when power has been					
		applied.					
		a-la la . , a au .					
		1. Power on the computer systems in					
		accordance with MS-252, Vol B, Section					
		5.10, Steps 6 -10. If you encounter					
		problems notify your supervisor.					

U.S. Postal Service	CODE ACRONYM CODE																
Maintenance Checklist					_			•						NUI	MBE	R	TYPE
	0	3	С	ı	0	S	S				Α	В	C)	0	1	М
Equipment Nomenclature	Equ	ipmer	nt Mo	del				Вι					Оссі	ırreı			
Combined Input Output Sub- System									M	IM1	4121				eC	BM	
System																	

				•			•
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	3
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
		2. IJP printers start up. Start up Imaje printers in accordance with Imaje S7 Supra Postal User Guide (PSN 7610-07-000-5515, P/N 0250235), Chapter 3, Page 3-1, and Paragraph A. Check printers for proper operation after restoring CIOSS to normal operating conditions.					
CIOSS SYSTEM: DIRECTORY DOWNLOAD	35.	Directory downloads FIN files from NDSS. Download FIN files as follows: WARNING Be cautious when working around or on equipment when power has been applied.	2	10		1200	
		From level three DIOSS Main Menu, select Disk Base Lookup.					
		From Disk Base Lookup Menu, select Reload FIN Files From NDSS.					
		3. Select YES to answer prompt, "Do you want to reload FIN files from NDSS?"					
		4. Click OK when message "Reload FIN files completed" appears.					
		5. Press F1 three times to return to Main Menu.					
CIOSS SYSTEM EMERGENCY AND INTERLOCK SWITCHES	36.	WARNING Be cautious when working around or on equipment when power has been applied. This task requires that the machine be running. Take precautions to prevent hair, clothing, jewelry, tools, and test equipment from being caught in moving parts. NOTE When performing this step, check only one interlock switch and one emergency stop switch with machine running. Check all other interlock and E-Stop switches while machine is stopped.	22	7			M
		Check all system interlocks and Emergency Stop					

U.S. Postal Service								IDE	NTIF	ICATI	ON					
Maintenance Checklist	CO	RK DE					MEN ⁻					ASS DE	N	UMBE	ER	TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	M
Equipment Nomenclature Combined Input Output Sub- System	Equi	ipmeı	nt Mo	del				В	ulletir N		name 4121	C	Occurr		СВМ	

Part or	Item			Task Statement and Instruction	Est.	Min.		Threshold	s
Component	No			(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
					Req (min)	Lev	Hours	Fed (000)	
					\)			(000)	
				s. Requires two people. Time is doubled					
				ing purposes. Verify light conditions and		l			
		war	nınç	g sounds for each E-Stop and interlock.		1			
		1.	Sta	rt machine. Verify that when START		l			
			swi	tch is pressed, start-up warning indicators		1			
				und sorter flash amber. At same time,		ļ			
				rt-up warning horns sound. The horns and for 5 seconds and go off, while		I			
				rning indicators flash for a total of 10		1			
				conds. Machine runs.		I			
		2.	Pre	ess EMERG STOP mushroom switch on		I			
				der control panel assembly and note that		I			
				owing occurs:		I			
			a.	Machine stops immediately.					
			b.	Lamp lights in EMERG STOP switch.		I			
			c.	Red EMERG STOP indicator lights on		l			
				appropriate system control panel		I			
				column.		l			
			d.	READY lamp goes out on system		l			
				control panel.		l			
			e.	Pressing Start pushbutton does not start		I			
				machine.		I			
		3.	Re	set EMERG STOP mushroom switch and		l			
			not	e that following occurs:		l			
			a.	System READY lamp illuminates on		l			
				system control panel.		l			
			b.	Red EMERG STOP indicator goes out		I			
			-	on appropriate system control panel		I			
				column.		l			
			C.	Lamp goes out in module control panel		l			
				EMERG STOP switch.		I			
			d.	Machine can now be started.		Ī			
			e.	Start machine. Verify that when START		l			
			-	switch is pressed, start-up warning		1			
				indicators around sorter flash amber. At		I			
				same time, start-up warning horns		I			
				sound. The horns sound for 5 seconds and go off, while warning indicators flash		1			
				for a total of 10 seconds. Machine runs.		I			
			f.	Open Reader module front panel door		l			
			1.	and note that the following occurs:		l			
				and hote that the following occurs.				1	

U.S. Postal Service								IDE	NTIFI	CATI	ON					
Maintenance Checklist		RK DE			_		MENT NYM	•			CLA CO		N	UMBE	ER	TYPE
	0	3	С	-	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equi	ipmer	nt Mo	del				В	ulletin N		name 4121	(Occurr		СВМ	

System			
Part or Iten Component No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Min. Time Skill Req Lev (min)	Run Pieces Freq. Hours Fed (000)
	1) Machine stops immediately. 2) Red EMERG STOP indicator goes out on appropriate system control panel column. 3) READY lamp goes out on system control panel. 4) Pressing Start pushbutton does not start machine. g. Close Reader module front panel door and note that the following occurs: 1) System READY lamp illuminates on system control panel. 2) Red EMERG STOP indicator goes out on appropriate system control panel column. h. Machine can now be started. 4. Without starting and stopping machine, check all remaining EMERG STOP mushroom switches one at time to ensure that each one causes actions as described in items 2-b, c, and d above to occur when pressed and actions described in items 3-a, b, and c above to occur when they are reset. 5. Without starting and stopping machine, check interlocks one at a time, by opening of panel or door, to ensure that each one causes actions described in items 2-c and d above to occur when opened and actions described in items 3-a and c occur when panel or door closed. When an interlock is activated in stacker, there will be an indication on stacker display panel. Red full bin lights will flash on top row of panel. When interlock is deactivated lights will go out. 6. If any problems are found, notify supervisor.		

U.S. Postal Service								IDE	NTIFI	CATI	ON					
Maintenance Checklist		RK DE			_		MENT NYM				CLA CO		N	UMBE	ER	TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equi	ipmer	nt Mo	del				В	ulletin N		name 4121	(Occurr		СВМ	

· ·							
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	3
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
·			Req	Lev	Hours	Fed	•
			(min)			(000)	
OLOGO OVOTEM	0.7	ID To a Decider Occident design of the least section of	4.5	40	1	1000	1
CIOSS SYSTEM	37.	ID Tag Reader System electrical enclosure	15	10		4800	
ICS READERS		inspection.					
INSPECT							
		WARNING					
		Be cautious when working around or					
		on equipment when power has been					
		applied.					
		applied.					
		Lies the most recent Maintenance Management					
		Use the most recent Maintenance Management					
		Order covering ICS ID-Tag reader system					
		electrical enclosure inspection to perform					
		procedures on all three ICS readers in order to					
		locate enclosures with defective power supplies,					
		switches not configured properly, incorrect					
		lamps, and lamps not installed properly.					
01000 01/0==::				4-	ļ	1000	
CIOSS SYSTEM	38.	Perform the following on all WFOV Read	16	10		4800	
WFOV		Head Assemblies on the CIOSS.					
ALIGNMENT							
		WARNING					
		Be cautious when working around or					
		on equipment when power has been					
		applied.					
		The WFOV Read Head Assembly (RHA) is					
		position-mounted on a spacer plate. On the					
		DBCS, DIOSS, and CIOSS the spacer plate					
		is secured to a mounting plate. Ensure the					
		Spacer Plate is properly aligned in					
		accordance with the most recent					
		documentation covering this procedure,					
		currently this will be MS-212 section 5.2.1.					
		2. Perform the WFOV Installation Alignment in					
		accordance with the most recent					
		documentation covering this procedure,					
		currently this will be MS-212 Section 5.2.2.1.					
		3. If any problems arise necessitating					
		corrective actions, write a work order to					
		document the time and events associated					
		with those problems.					
ADDRESS	39.	Perform the following to Purge the PostJet	3	9	<u> </u>	1	
PRINTER	55.	High Speed Label Applicator Printer:	3			'	
MODULE: PURGE		gpeea =aae. / ippiioater i iiiteri					
WODULL, FUNGE	l			l	L	L	l

U.S. Postal Service	IDENTIFICATION													
Maintenance Checklist	WORK CODE		EQUIPMENT ACRONYM						CLASS CODE		NUMBER		TYPE	
	0 3	С		0	S	S			Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equipme	nt Mod	del				E	Bulletin File MM1	name 4121	(Occurr		CBM	

Part or	Item	Task Statement and Instruction	Est.	Min.	Thresholds			
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.	
		WARNING						
		Be cautious when working around or on equipment when power has been applied.						
		Check the area around the PostJet Printer Nozzle Assembly for dirt and debris. If necessary write a work order to clean.						
		Press "Yellow Short Purge" or "Red Long Purge" Button.						
		3. Using approved wipe (PSN 5836-13-000-7200) quickly wipe across the face plate of the print station horizontally in the direction of mail flow to remove the ejected ink.						
		Using the PostJet Priming Vacuum Pump, clean the nozzle plate using existing procedures, even if all nozzles are present during test fire.						
		5. Hold a blank test card or equivalent in front of the nozzles and press the "Green Test Fire" Button.						
		Inspect card to verify all dots are present. If not repeat procedure.						
		7. For more detail refer to the manufacturer's manual located on the MTSC CIOSS Equipment web page.						
		If problems are found notify your supervisor and generate a work order.						
OCR/TAG PRINTER MODULE IMAJE ID TAG PRINTER	40.	Perform an auto-calibration on the ID Tag Imaje IJP.	60	10		4800		
		WARNING						
		Be cautious when working around or on equipment when power has been applied. This task requires that the machine be running. Take precautions to prevent hair, clothing, jewelry, tools, and test equipment from being caught in moving parts.						

U.S. Postal Service								IDE	NTIFI	CAT	ION					
Maintenance Checklist	_	RK DE					MENT MYMC	•			CLA CO	ASS DE	1	NUME	ER	TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equ	ipmer	nt Mo	del				В	ulletin N		name 4121		Occu	rence e	CBM	

Part or Component No Task Statement and Instruction Est. Time Skill Run Pieces Freq. Fre	Component No (Comply with all current safety precautions) Time Req (min) WARNING When disposing of ink or ink-saturated waste, refer to procedures outlined in Safety Data Sheets (SDS) and local procedures already established. Eye protection (Goggles or face shield) must be worn when flushing away	Component No (Comply with all current safety precautions) Time Req Lev Hours Fed		System							
When disposing of ink or ink-saturated waste, refer to procedures outlined in Safety Data Sheets (SDS) and local procedures already established. Eye protection (Goggles or face shield) must be worn when flushing away contaminants using replenisher. WARNING The Imaje Ink Jet Printer (IJP) must be dried as part of its service. Do not use compressed or blown air. Appropriate, alternate means of drying the head must be implemented and may include the use of paper towels or use of vacuum suction. Other equally effective methods may be determined locally. Refer to Imaje S7 Supra Postal User Guide (PSN 7610-07-000-5515, P/N 0250235), Chapter 4, Page 4-7, Paragraph F. FEEDER MODULE ALIGNMENT CHECK W/POWER Be cautious when working around or on equipment when power has been applied. Check Feeder alignment (Power On steps) using template, PSN 5220-04-000-5005, and in accordance with most recent MMO, currently MMO-029-08, covering feeder alignment and	WARNING When disposing of ink or ink-saturated waste, refer to procedures outlined in Safety Data Sheets (SDS) and local procedures already established. Eye protection (Goggles or face shield) must be worn when flushing away	(min) (000)	Component No (Comply with all current safety precautions) Time Skill Run Pieces Freq. Req Lev Hours Fed				Time Req	Skill		Pieces Fed	
NOTE If any discrepancies are found, write a work order to do a full feeder alignment in	The Imaje Ink Jet Printer (IJP) must be dried as part of its service. Do not use compressed or blown air. Appropriate, alternate means of drying the head must be implemented and may include the use of paper towels or use of	When disposing of ink or ink-saturated waste, refer to procedures outlined in Safety Data Sheets (SDS) and local procedures already established. Eye protection (Goggles or face shield) must be worn when flushing away		ALIGNMENT CHECK	41.	When disposing of ink or ink-saturated waste, refer to procedures outlined in Safety Data Sheets (SDS) and local procedures already established. Eye protection (Goggles or face shield) must be worn when flushing away contaminants using replenisher. WARNING The Imaje Ink Jet Printer (IJP) must be dried as part of its service. Do not use compressed or blown air. Appropriate, alternate means of drying the head must be implemented and may include the use of paper towels or use of vacuum suction. Other equally effective methods may be determined locally. Refer to Imaje S7 Supra Postal User Guide (PSN 7610-07-000-5515, P/N 0250235), Chapter 4, Page 4-7, Paragraph F. Check Feeder alignment. WARNING Be cautious when working around or on equipment when power has been applied. Check Feeder alignment (Power On steps) using template, PSN 5220-04-000-5005, and in	(min)		Hours	(000)	
ALIGNMENT CHECK W/POWER Be cautious when working around or on equipment when power has been applied. Check Feeder alignment (Power On steps) using template, PSN 5220-04-000-5005, and in accordance with most recent MMO, currently MMO-029-08, covering feeder alignment and	vacuum suction. Other equally	The Imaje Ink Jet Printer (IJP) must be dried as part of its service. Do not use compressed or blown air. Appropriate, alternate means of drying the head must be implemented and may include the use of paper towels or use of	When disposing of ink or ink-saturated waste, refer to procedures outlined in Safety Data Sheets (SDS) and local procedures already established. Eye protection (Goggles or face shield) must be worn when flushing away contaminants using replenisher. WARNING The Imaje Ink Jet Printer (IJP) must be dried as part of its service. Do not use compressed or blown air. Appropriate, alternate means of drying the head must be implemented and may include the use of paper towels or use of	FEEDER MODULE	41.	effective methods may be determined locally. Refer to Imaje S7 Supra Postal User Guide (PSN 7610-07-000-5515, P/N 0250235), Chapter 4, Page 4-7, Paragraph F.		7		1200	

U.S. Postal Service								IDE	NTIFI	CATI	ION					
Maintenance Checklist	WO				_		MENT DNYM	•			CLA CO	ASS DE	N	UMBE	ER	TYPE
	0	3	С	I	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equi	pmeı	nt Mo	del				В	ulletin N		name 4121	(Occurr		СВМ	

Oystem							
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	1
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
			Req (min)	Lev	Hours	Fed (000)	
	l		(111111)			(000)	
READER	42.	Power supply PS1 (5VDC Reader)	5	9		15600	
MODULE: POWER	72.	adjustment.	3	5		10000	
SUPPLY		aajaaamena					
		WARNING					
		De soutieus when wenking ground er					
		Be cautious when working around or on equipment when power has been applied.					
		Open Reader lower left door.					
		Place multimeter leads with clips on connectors J14 and J15 of Reader card cage backplane.					
		3. A reading of 5.1 VDC should be present, if not adjust, 5 VDC power supply potentiometer to obtain a reading of +5.0 VDC (+0.1/-0.0 VDC).					
		4. Close door.					
LEVELER MODULE	43.	Perform an auto-calibration on the POSTNET Imaje IJPs.	60	10		4800	
IMAJE POSTNET IJP		WARNING					
		Be cautious when working around or on equipment when power has been applied. This task requires that the machine be running. Take precautions to prevent hair, clothing, jewelry, tools, and test equipment from being caught in moving parts.					
		WARNING					
		When disposing of ink or ink-saturated waste, refer to procedures outlined in Safety Data Sheets (SDS) and local procedures already established. Eye protection (Goggles or face shield) must be worn when flushing away contaminants using replenisher.					
		WARNING					

U.S. Postal Service								IDE	NTIFI	CAT	ON						
Maintenance Checklist		RK DE			_		MENT DNYM	•			CL/ CO			NUI	MBE	R	TYPE
	0	3	С	ı	0	S	S				Α	В	C)	0	1	М
Equipment Nomenclature Combined Input Output Sub-	Equ	ipmer	nt Mo	del				Вι	ulletin M		name 4121		Occı	ırreı		свм	
System									IVI	IIVI I	7121				-	וויוטכ	

Det	14	Tools Obstances 111 111	T = :	N 4:		There is a second	
Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Thresholds	
Component	INO	(Comply with all current salety precautions)	Req	Lev	Run Hours	Pieces Fed	Freq.
			(min)			(000)	
				l	1	1	
		The Imaje Ink Jet Printer (IJP) must be					
		dried as part of its service. Do not use					
		compressed or blown air. Appropriate,					
		alternate means of drying the head					
		must be implemented and may include					
		the use of paper towels or use of vacuum suction. Other equally					
		effective methods may be determined					
		locally.					
		•					
		Refer to Imaje S7 Supra Postal User Guide					
		(PSN 7610-07-000-5515, P/N 0250235),					
		Chapter 4, Page 4-7, Paragraph F.					
STACKER	44.	Stacker bin-full switch checks.	7	7		1200	
MODULE: FULL		WARNING					
BIN SWITCH		WARNING					
CHECK		Be cautious when working around or					
		on equipment when power has been					
		applied.					
		прр					
		1. Pull each stacker blade to its 3/4 full					
		position, and note that it's associated red					
		indicator on stacker module display panel					
		flashes and stacker module horn beeps. Note defective stacker switches.					
		2. Pull each stacker blade to its full position,					
		and note that its associated red indicator on					
		stacker module display panel is constantly illuminated and stacker module horn beeps.					
		Note defective stacker switches.					
		3. Verify the stacker blade rides smoothly on the guide rod					
		the guide rod.					
		4. Notify supervisor of defective stacker					
		switches and initiate a work order to repair or					
		replace as necessary.					
STACKER	45.	Power supply adjust PS1 - 5 volts (stackers).	14	9		15600	
MODULES:		<u> </u>					
POWER SUPPLY		WARNING					
		Be cautious when working around or					
		on equipment when power has been					
		applied.					
		1. Place multimeter leads with clips on					

U.S. Postal Service								IDE	NTIFI	CAT	ION						
Maintenance Checklist		RK DE			_		MENT NYM	•				ASS DE		NUI	MBE	R	TYPE
	0	3	С	ı	0	S	S				Α	В	C)	0	1	М
Equipment Nomenclature	Equ	ipmer	nt Mo	del				Вι	ulletin				Оссі	ırreı			
Combined Input Output Sub- System									M	IM1	4121				eC	CBM	
System																	

Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	
Component	No	(Comply with all current safety precautions)	Time Req	Skill Lev	Run Hours	Pieces Fed	Freq.
			(min)	LEV	Hours	(000)	
			()		1	(000)	
		connectors J10 and J11 of the stacker					
		backplane.					
		2. A reading of 5.1 VDC should be present, if					
		not adjust the power supply potentiometer to					
		obtain a reading of +5.0 VDC					
		(+0.1/-0.0 VDC).					
STACKER	46.	Gate and solenoid pusher assembly test.	20	9		14300	
MODULES: GATE SOLENOID PUSHERS		WARNING					
FUSITERS		Be cautious when working around or on					
		equipment when power has been applied.					
		1. Main Menu, select following maintenance					
		test: Maintenance-Systems Tests-Stacker					
		Module Test-Gate Activation Test.					
		2. At the Gate Activation Test screen select					
		the following: Select Stackers-All, Select					
		Gates-All, and Select Action-Sequence.					
		NOTE					
		Identify visually inoperative solenoid					
		pusher assemblies and gates by viewing					
		each stacker module one by one.					
		3. One stacker module will be tested at a time,					
		energizing every gate and solenoid pusher					
		assembly sequentially, repeatedly. By responding to the testing screen on the					
		DBCS monitor and answering Yes or No,					
		the test will move to the next stacker					
		module. The testing will be identical for					
		each stacker module.					
		4. Type T to begin-Start Test.					
		5. Verify gate and pusher solenoids are firing					
		in each stacker. Also verify driver module					
		LEDs are operating for each gate and					
		pusher. Green LED is for power and amber					
		LED blinks when a solenoid is to be					
		energized.					
		6. Refer to safety bulletin MMO-035-04 for					
		corrective procedures and additional			<u> </u>		

U.S. Postal Service								IDE	NTIFI	CAT	ON						
Maintenance Checklist		RK DE			_		MENT DNYM	•			CL/ CO			NUI	MBE	R	TYPE
	0	3	С	ı	0	S	S				Α	В	C)	0	1	М
Equipment Nomenclature Combined Input Output Sub-	Equ	ipmer	nt Mo	del				Вι	ulletin M		name 4121		Occı	ırreı		свм	
System									IVI	IIVI I	7121				-	וויוטכ	

System							
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	S
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
			Req (min)	Lev	Hours	Fed (000)	
			(111111)			(000)	
		information.					
		7. Exit maintenance menu.					
		7. Exit maintenance mend.					
CIOSS	47.	Mail path validation. Check basic machine	4	9		3	
VALIDATION		functions as follows:					
MACHINE VALIDATION		WARNING					
		Be cautious when working around or on equipment when power has been applied. This task requires that the machine be running. Take precautions to prevent hair, clothing, jewelry, tools, and test equipment from being caught in moving parts.					
		 Turn Maintenance Mode key switch on operator control panel to MAINT position. Start machine. 					
		 Start machine. Verify when START switch is pressed, start-up warning indicators around sorter flash amber. At the same time, start- up warning horns sound. Horns sound for 5 seconds and go off, while warning indicators continue to flash for a total of 10 seconds. 					
		3. Do a visual and audible check of machine to verify there are no problems with belt tracking, bearing noise, inappropriate bin gate activity, or any indications of impending or existing machine problems.					
		 Proceed to end stacker and press Emergency Stop button. Verify machine stops. 					
		 If machine fails to stop, notify supervisor and refer to the most recent Maintenance Management Order or document covering the SBK-11 Backplane Switch Configuration. 					
		De-activate E-Stop and turn Maintenance Mode switch back to NORMAL on operator control panel.					
CIOSS	48.	POSTNET IJP validation. Check POSTNET	4	10		3	
VALIDATION		bar code printing as follows:					
POSTNET IJP		WARNING					1
VALIDATION		THE CONTRACT OF THE CONTRACT O					1

U.S. Postal Service								IDE	NTIFI	CAT	ION						
Maintenance Checklist		RK DE			_		MENT NYM	•				ASS DE		NUI	MBE	R	TYPE
	0	3	С	ı	0	S	S				Α	В	C)	0	1	М
Equipment Nomenclature	Equ	ipmer	nt Mo	del				Вι	ulletin				Оссі	ırreı			
Combined Input Output Sub- System									M	IM1	4121				eC	CBM	
System																	

Oysteili							
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	s
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
		,	Req	Lev	Hours	Fed	·
	<u> </u>		(min)			(000)	
		Be cautious when working around or					
		on equipment when power has been					
		applied. This task requires that the machine be running. Take precautions					
		to prevent hair, clothing, jewelry, tools,					
		and test equipment from being caught					
		in moving parts.					
		1. From Main Menu, select Maintenance,					
		System Tests, and then Bar Code Printer					
		Test.					
		2. At ZIP Code field, type in a 5 digit ZIP Code.					
		3. At Carrier Route field, type in from 1-4 ASCII					
		characters.					
		4. Press F2 key.					
		5. Start machine with control panel					
		MAINTENANCE MODE key in NORMAL					
		mode and feed five blank cards					
		(PSN 5220-03-000-5975, P/N CO-2823NH).					
		NOTE					
		Right edge of letter to left framing bar					
		should be 4 1/8" to 4 1/4". Bottom of bars should be even and 1/4" +/- 1/16" above					
		bottom edge.					
		Check bar codes for location and quality.					
		7. If necessary, align with procedures found in					
		the most recent documentation, presently					
		that is the MS 252, Volume B, Paragraph					
		6.12.2, POSTNET Print Head Adjustment,					
		and repeat test.					
		8. Once satisfactory bar codes are sprayed,					
		press F1 key three times to return to Main					
		Menu screen. If satisfactory bar codes					
		cannot be obtained write a work order to properly correct the problem.					
CIOSS	49.	ID Tag IJP validation. Check ID Tag as	2	10		3	
VALIDATION		follows:					
ID TAG IJP PRINTER		WARNING					
VALIDATION							
		Be cautious when working around or					
		on equipment when power has been					
		applied. This task requires that the machine be running. Take precautions					
	1	macimie be ruilling. Take precautions			<u> </u>	<u> </u>	1

U.S. Postal Service								IDE	NTIFI	CATI	ON						
Maintenance Checklist	WORK EQUIPMEN CODE ACRONYM										CLA CO		N	UMBE	ER	TYPE	
	0	3	С	ı	0	S	S				Α	В	0	0	1	М	
Equipment Nomenclature Combined Input Output Sub- System	Equi	Equipment Model								Bulletin Filename MM14121				Occurrence eCBM			

System							
Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	3
Component	No	(Comply with all current safety precautions)	Time	Skill	Run	Pieces	Freq.
			Req (min)	Lev	Hours	Fed (000)	
		to prevent hair, clothing, jewelry, tools,					
		and test equipment from being caught					
		in moving parts.					
		From Main Menu, select Maintenance, System Tests, and then ID Tag Printer Test.					
		2. Fill in fields as follows:					
		a. Machine Number - between 1-3999.					
		b. Time of Day - between 0-47.					
		c. Day of Month - between 1 - 31.					
		d. Sequence Number - between 1-25,000.					
		e. Mail Class - 1 or 3.					
		3. Press F2 key.					
		 Start machine with MAINTENANCE MODE key in NORMAL mode and feed five blank cards, PSN 5220-03-000-5975, P/N CO- 2823NH. 					
		 Check ID Tag quality and position using the ID TAG template, PSN 9330-03-000-6399, P/N MM959601. 					
		 Make adjustments to Control Module P- IJP02 circuit board and/or ID Tag printer, if needed, refer to the most recent documentation; presently that is the MS-252 Volume B, Paragraph 6.6.11 ID Tag Printer Print Head Adjustment. Repeat test, if necessary. 					
		7. Save above 5 cards for ICS validation.					
		 Once satisfactory bar codes are sprayed, press F1 key three times to return to Main Menu screen. If satisfactory barcodes cannot be obtained, write a work order to properly correct the problem. 					
CIOSS VALIDATION ICS READER	50.	ICS Reader validation. Validate ICS-3 readers as follows:	7	10		3	
VALIDATION		WARNING					
		Be cautious when working around or on equipment when power has been applied. This task requires that the machine be running. Take precautions					

U.S. Postal Service								IDE	IDENTIFICATION								
Maintenance Checklist		WORK EQUIPMENT CODE ACRONYM										ASS DE	NUMBER				TYPE
	0	3	C I O S S								Α	В	C)	0	1	М
Equipment Nomenclature	Equipment Model								ulletin				Occurrence				
Combined Input Output Sub- System	MM14121 eCBM									BM							
System																	

Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	S
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
		to prevent hair, clothing, jewelry, tools, and test equipment from being caught in moving parts.					
		Set machine up to run in ISS/OCR mode.					
		From ON LINE MAIL PROCESSING screen, select Display ZIPs/Pkts.					
		From Select Display Option screen, select On Line Display.					
		Start machine and re-run 5 test cards saved from the ID Tag IJP validation.					
		 At On Line Display Screen, verify that ICS-3 Pre-reader and ICS-3 Verifier detected 5 ID Tags present and they read the same. 					
		6. Stop the machine.					
		7. Retrieve the cards from the stackers.					
		Start machine and re-run 5 test cards with the ID Tags facing to the front.					
		9. Stop the machine.					
		10. Press F1 key to return to ON LINE MAIL PROCESSING screen.					
		11. Press F1 key to stop mail processing. Click on Yes to exit run and click on Yes to print an End of Run Report.					
		 Validate on End of Run report that ID Tags were detected by OSR (opposite side ICS reader). 					
CIOSS	51.	Run the ICS Stress Test Deck by doing the	7	9		3	
VALIDATION ICS STRESS TEST		following: WARNING					
		Be cautious when working around or on equipment when power has been applied. This task requires that the machine be running. Take precautions to prevent hair, clothing, jewelry, tools, and test equipment from being caught in moving parts.					
		Set machine to run DBCS mode using Sort Plan icstst1.ebf or icstst2.ebf.					
		Start machine and run the stress deck, PSN					

U.S. Postal Service								IDE	NTIFI	CATI	ON						
Maintenance Checklist	WORK EQUIPMEN CODE ACRONYM										CLA CO		N	UMBE	ER	TYPE	
	0	3	С	ı	0	S	S				Α	В	0	0	1	М	
Equipment Nomenclature Combined Input Output Sub- System	Equi	Equipment Model								Bulletin Filename MM14121				Occurrence eCBM			

System									
Part or	Item		ment and Instruction		Est.	Min.	,	Thresholds	3
Component	No	(Comply with all	current safety precautions	s)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
		belts.	1, in normal mail g facing toward the fo run, select Interin						
		Para. 1.7 ID Ta ICS-3 Pre-Read detected all ID T	splay screen, scroll dag Report and veri der and ICS-3 of ags present and the fneeded, print the re	ify that Verifier at they					
		accordance wi Maintenance M document cover	Management Ordering the procedure ID Tag Reader S	current er or es for					
			cedure with mail o ig out from feeder be						
			n Report verify th eader detected all II d print the report.						
		work order, and re the most current I Order, currently N sorting problems.	Test Deck fails, write efer to the procedure Maintenance Manage MMO-144-15, dealing	es in ement g with					
CIOSS VALIDATION HSLA ADDRESS	52.	ISLA validation, ad Doubles Detector va			9	9		3	
PRINTER/DOUBLE		W	ARNING						
DETECTOR VALIDATION		on equipment w applied. This t machine be runn to prevent hair, o	en working around when power has be ask requires that ing. Take precaution clothing, jewelry, to ent from being cau	een the ons ols,					
		. Select Maintenan	ce from the Main me	enu.					
		 Select System Te menu. 	st from Maintenance						
		 Select Label Mod 	ule Test from the Sys	stem					

U.S. Postal Service					IDENTIFICATION												
Maintenance Checklist	WORK CODE					MEN ⁻ NYM				ASS DE	Ν	UMBE	ĒR	TYPE			
	0 3	С	I	0	S	S			Α	В	0	0	1	М			
Equipment Nomenclature Combined Input Output Sub- System	Equipme	nt Mod	del				E	Bulletin File MM1	name 4121	(Occurr		CBM				

Oystelli							
Part or	Item	Task Statement and Instruction	Est.	Min.		Threshold	
Component	No	(Comply with all current safety precautions)	Time Req	Skill Lev	Run Hours	Pieces Fed	Freq.
			(min)			(000)	
		Test menu.					
		Select Label Test from Label Module Test					
		menu.					
		5. On the Label Test screen, select following:					
		a. Label Applicator #1.					
		b. Label Applicator #2.					
		c. Print Bar code.					
		d. Label Printer.					
		6. Using documents from Doubles Detector test deck, (PSN 3915-07-000-0157, P/N 506-03184-00), insert documents at an interval of approximately 1/8 to 1/4 inches into a deck of blank cards (9.5" x 4.25" part of PSN 3915-07-000-0155, P/N 506-03171-00).					
		7. Start the machine by pressing Start button.					
		8. Verify the cards are sorted to the correct pockets, Label OK LA1 and Label OK LA2.					
		Visually verify address and bar code information is legible and free from streaks or other anomalies.					
		 Verify label is placed properly on card stock. Label should be place 1 - 2 mm from bottom of document and 5 mm ± 3 mm from the leading edge of document. 					
		11. Verify documents from the Doubles Detector test deck are sorted to the doubles pocket.					
CIOSS VALIDATION OCR VALIDATION	53.	OCR validation. WARNING	3	10		3	
		Be cautious when working around or on equipment when power has been applied. This task requires that the machine be running. Take precautions to prevent hair, clothing, jewelry, tools, and test equipment from being caught in moving parts.					
		Press Maintenance button on Main Menu screen.					
		Press System Tests button on Maintenance					

U.S. Postal Service								IDE	NTIFIC	ATI	ON					
Maintenance Checklist	WC CO	RK DE		_		MENT NYM	•			CLA CO		N	UMBE	ĒR	TYPE	
	0	3	C I O S S								Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equ	ipmer	nt Mo	del				В	Bulletin Filename MM14121				Occurrence eCBM			

Part or	Item	Task Statement and Instruction	Est.	Min.		Thresholds	
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
		screen.					
		Press the Sort Tests button on the System Tests screen.					
		Press the OCR Test Deck button on the Sort Tests screen.					
		Press Start OCR Test Deck button on the OCR Test Deck screen.					
		6. Run the test deck (PSN 3915-07-000-0160, P/N 506-03192-00).					
		7. When finished running the test deck, press Stop OCR Test Deck.					
		8. Report will automatically be displayed on screen. To print the report, press the Print button at the top of the screen.					
		9. Log off the system computer.					
CIOSS VALIDATION WFOV 400 PIECE	54.	In OCR Mode, run the WFOV 400 piece test deck to verify proper GAR and that both readers are reading.	9	9		3	
TEST DECK		WARNING					
		Be cautious when working around or on equipment when power has been applied. This task requires that the machine be running. Take precautions to prevent hair, clothing, jewelry, tools, and test equipment from being caught in moving parts.					
		NOTE					
		Ensure that read head aperture is clean.					
		Using WFOV 400 piece test deck (PSN 3915-06-000-8292, P/N 237A073-2), perform following at Main Menu:					
		Select Mail Processing.					
		2. Load Run Information.					
		3. Enter 750 for operation number.					
		4. Press F2.					
		5. Load Sortplan.					

U.S. Postal Service								IDE	NTIF	CAT	ION					
Maintenance Checklist	WORK EQUIPMENT CODE ACRONYM										CLA CO	ASS DE	1	IUMB	TYPE	
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equipment							В	ulletin N		name 4121		Occu	rence e	CBM	

U.S. Postal Service								IDE	NTIF	ICATI	ON					
Maintenance Checklist	CO	RK DE					MEN ⁻					ASS DE	N	UMBE	ER	TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	M
Equipment Nomenclature Combined Input Output Sub- System	Equi	ipmeı	nt Mo	del				В	ulletir N		name 4121	C	Occurr		СВМ	

				T. 1.0(1)	T =			_,	
Part or Component	Item No			Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill	Run	Threshold Pieces	Freq.
Component	110			(Comply with all current salety precautions)	Req	Lev	Hours	Fed	rieq.
					(min)			(000)	
			e.	Select F2 to accept.					
			f.	Load a sort plan that has a confirmed					
				UAA pocket assigned. (PARS Special Pockets.ebf assigns pocket 39 for UAA)					
			g.	Start Mail Run.					
			h.	Access System Components menu.					
			i.	Disable Barcode IJP.					
			j.	Start mail processing and run UAA test deck.					
			k.	Access System Component menu.					
			I.	Enable Barcode IJP.					
			m.	Print the end of run report.					
			n.	Calculate the intercept rate (# confirmed UAA test pieces divided by the total # of test pieces fed, multiplied by 100).					
			0.	Verify that at least 90% of the UAA test deck was intercepted.					
		2.		rify that OCR engine in DBCS mode can ercept UAA with bar coded mail:					
			000	ing Xanadu Test Deck, PSN 9310-08- 0-3864, P/N 66.1026.034-00, do the owing:					
			a.	Select Mode Select.					
			b.	DBCS.					
			c.	Load Run Information.					
			d.	Enter Operation Number.					
			e.	Select F2 to accept.					
			f.	Load a sortplan that has a confirmed UAA pocket assigned. (ParsSpecial Pockets.ebf assigns pocket 39 for UAA.)					
			g.	Start Mail Processing and run UAA test deck.					
			h.	Print End of Run report.					
			i.	Calculate intercept rate (# confirmed UAA test pieces divided by total # of test pieces fed, multiplied by 100).					

U.S. Postal Service						IDE	ENTIFI	CATI	ON						
Maintenance Checklist	WORK CODE				MENT MYNC					ASS DE		Νl	JMBE	ĒR	TYPE
	0 3	CI	0	S	S				Α	В		0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equipmer	nt Model				В	Bulletin I V		name 4121		Oc	curr	ence e(СВМ	

Part or	Item	Task Statement and Instruction	Est.	Min.	-	Thresholds	;
Component	No	(Comply with all current safety precautions)	Time Req (min)		Run Hours	Pieces Fed (000)	Freq.
		 Verify that at least 90% of the UAA tes deck was intercepted. 	t				
		k. Log off system computer.					
PREDICTIVE MAINT. ULTRASONIC	56.	Predictive maintenance tasks and procedures.	230	10		20000	
AND INFRARED		WARNING					
SCANS		Be cautious when working around or on equipment when power has been applied. This task requires that the machine be running. Take precautions to prevent hair, clothing, jewelry, tools, and test equipment from being caught in moving parts.					
		NOTE					
		While performing all of the PdM tasks, make a note of any area where excessive vibration, noise, and/or heat are detected. Recommend using the PdM Form found on the MTSC web site to facilitate recording areas of questionable bearings. Initiate a work order to cover any annotated area that requires additional investigation.					
		1. Prepare machine.					
		 Perform shutdown procedures for the CIOSS in accordance with the Image S Supra printer manual Chapter 3 and th MS-252 Vol. B, Sec. 5-3. 					
		 Power down the machine and lock out its electrical power as prescribed by th current local lockout instructions providing lockout/restore procedures. 					
		c. Open covers and remove panels.					
		d. Open all machine doors including Ma AC Power Panel, Feeder Distribution Panel, and Motor Distribution Par Open or remove all machine panels, to includes diverter plate cover assemblity (Wimpy panels).	on nel nis				
		e. Override interlock switches.					

U.S. Postal Service								IDE	NTIF	ICAT	ION						
Maintenance Checklist	_	RK DE					MEN NYNC					ASS DE		ΝL	JMBE	R	TYPE
	0	3	С	I	0	S	S				Α	В	()	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equi	ipmer	nt Mo	del				В	ulletin N		name 4121		Occ	urre	ence e(СВМ	

System									
Part or	Itom	1	Task Statement and Instruction		Est.	Min.		Thresholds	
Component	Item No		(Comply with all current safety precaution	ns)	Time	Skill	Run	Pieces	Freq.
	1			,	Req	Lev	Hours	Fed	
					(min)			(000)	
			NOTE						
			r Main Power Unit must by-pass netic contacts for CIOSS to run. Restore power to equipment in accordance with MS-252 Vol. B	s the					
			Sec 5.10 and current local procedurously providing lockout/restore procedurously						
			NOTE	1100					
		Mac	hine must have been running f	or a					
		mini	mum of 15 minutes prior to doing sonic and infrared scans.						
		2. Ultr	asonic scans.						
			NOTE						
			the Long Range Module (cone Ultra-Probe when doing the ultras ns.						
		a.	Use ultrasonic detector to more bearing assemblies, top and be the Feeder, for excessive vibrat noise.	ottom of					
		b.	Use ultrasonic detector to more bearing assemblies, top and be the Transport, for excessive vand noise.	ottom of					
		C.	Use ultrasonic detector to more bearing assemblies, top and be the Drying Turn module, for exvibration and noise.	ottom of					
		d.	Use ultrasonic detector to more bearing assemblies, top and be the OCR/Tag Printer modu excessive vibration and noise.	ottom of					
		e.	Use ultrasonic detector to more bearing assemblies, top and be the Left Computer Rack modexcessive vibration and noise.	ottom of					
		f.	Use ultrasonic detector to more bearing assemblies, top and both High Speed Label Applicator more excessive vibration and noise.	ottom of					
		g.	Use ultrasonic detector to mor	nitor all					

U.S. Postal Service								IDE	NTIF	CAT	ION					
Maintenance Checklist	_	RK DE					MENT MYMC	•			CLA CO	ASS DE	1	IUMB	ER	TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equ	ipmer	nt Mo	del				В	ulletin N		name 4121		Occu	rence e	CBM	

System							
Part or Item Component No		Task Statement and Instruction (Comply with all current safety precautions)	Est. Time Req (min)	Min. Skill Lev	Run Hours	Threshold Pieces Fed (000)	Freq.
		bearing assemblies, top and bottom of the Address Printer module, for excessive vibration and noise.					
	h	Use ultrasonic detector to monitor all bearing assemblies, top and bottom of the Right Computer Rack module, for excessive vibration and noise.					
	i.	Use ultrasonic detector to monitor all bearing assemblies, top and bottom of the Reader module, for excessive vibration and noise.					
	j.	Use ultrasonic detector to monitor all bearing assemblies, top and bottom of the Leveler module, for excessive vibration and noise.					
	k	Use ultrasonic detector to monitor all bearing assemblies, top and bottom of Motor Power Distribution, for excessive vibration and noise.					
	I.	Use ultrasonic detector to monitor all bearing assemblies, top and bottom of the Drying Transport module, for excessive vibration and noise.					
	n	b. Use ultrasonic detector to monitor all bearing assemblies, top and bottom of Tiers 1-4 of the Stacker modules, for excessive vibration and noise.					
	3. lı	frared scans.					
	а	. Use non-contact infrared to scan Main Power Unit front and rear (magnetic interlock on panel).					
	b	Start CIOSS machine, the machine must be running a minimum of 15 minutes before using non-contact infrared thermometer.					
	C	Scan all terminal connections and connector plugs.					
	d	Use non-contact infrared to monitor all motors, terminal connections, and connector plugs in the Feeder for abnormal temperature.					
	e	. Use non-contact infrared to monitor all					

U.S. Postal Service								IDE	NTIFIC	ATI	ON					
Maintenance Checklist	WORK CODE				_		MENT NYM	•			CLA CO		N	UMBE	ĒR	TYPE
	0	3	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equ	ipmer	nt Mo	del				В	ulletin F M I		name 4121		Occurr		СВМ	

Part or	Item		Task Statement and Instruction	Est.	Min.		Threshold	s
Component	No		(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq
			terminal connections and connection plugs in the Feeder Distribution Panel for abnormal temperature.					
		f.	Use non-contact infrared to monitor all motors, terminal connections, and connector plugs in the Transport for abnormal temperature.					
		g.	Use non-contact infrared to monitor all terminal connections and connection plugs in the Drying Turn module for abnormal temperature.					
		h.	Use non-contact infrared to monitor all terminal connections and connection plugs in the OCR/Tag Printer module for abnormal temperature.					
		i.	Use non-contact infrared to monitor all terminal connections and connection plugs in the Left Computer Rack module for abnormal temperature.					
		j.	Use non-contact infrared to monitor all terminal connections and connector plugs in the High Speed Label Applicator module for abnormal temperature.					
		k.	Use non-contact infrared to monitor all terminal connections and connection plugs in the Address Printer module for abnormal temperature.					
		l.	Use non-contact infrared to monitor all terminal connections and connection plugs in the Right Computer Rack module for abnormal temperature.					
		m.	Use non-contact infrared to monitor to scan all terminal connections and connection plugs in the Drying Transport module for abnormal temperature.					
		n.	Use non-contact infrared to monitor all terminal connections and connection plugs in Leveler module for abnormal temperature.					
		0.	Use non-contact infrared to monitor all motors, terminal connections, and connector plugs in the Reader module for abnormal temperature.					

U.S. Postal Service								IDE	NTIF	CAT	ON					
Maintenance Checklist	WORK CODE						MENT MYNC					ASS DE	N	IUMBI	ER	TYPE
	0	3	O	-	0	S	S				Α	В	0	0	1	M
Equipment Nomenclature Combined Input Output Sub- System	Equi	ipmer	nt Mo	del			·	В	ulletin N		name 4121		Occur		СВМ	

Part or	Item		Task Statement and Instruction	Est.	Min.		Thresholds	S
Component	No		(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
		ţ	Use non-contact infrared to monitor all terminal connections and connector plugs in the Motor Distribution Panel for abnormal temperature.					
		C	Use non-contact infrared to monitor all terminal connections and connector plugs in the Stacker Modules, Tiers 1-4 for abnormal temperature.					
		4. F	estore equipment to ready status.					
		8	Perform Power Down procedures as described in Step 1 sub-steps a and b of this document.					
		k	Replace all machine panels. Close all machine doors and covers. Report all deficiencies to your supervisor.					
		C	Restore power by performing the Power Up procedures in accordance with MS-252, Vol. B, Sec 5.10 and current local procedures providing lockout / restore procedures and the Image S7 manual chapter 3 for the Ink Jet Printers.					
FINAL CLEAN UP	57.	are r	n up. Ensure all tools, lubricants, rags, etc., emoved from the work area. Report all encies to your supervisor.	4	All			

ATTACHMENT 3

CIOSS MASTER CHECKLIST

09-CIOSS-AB-001-M

Operational Maintenance

Task Item Number	Basic Task Time Min.	Times Done During Tour	Total Time per Tour Min.
1	1	1	1
2	1	1	1
3	1	3	3
4	1	3	3
5	1	3	3
6	1	3	3
7	3	3	9
8	2	3	6
9	2	3	6
10	2	2	4
11	2	3	6
12	1	3	3
13	2	3	6
14	2	3	6
15	5	3	15
16	2	1	2
		Total OPM Time	77

U.S. Postal Service		ID						IDE	IDENTIFICATION										
Maintenance Checklist	_	ORK ODE			_		MEN NYNC	-			CLASS CODE		NUMBER			TYPE			
	0	9	С	ı	0	S	S				Α	В	0	0	1	М			
Equipment Nomenclature Combined Input Output Sub- System	Equ	Equipment Model						В	ulletir N		name 4121		Occurr		our				

System							
Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill	,	Thresholds	3
33		(comp.) min all called procautions)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
SAFETY STATEMENT		COMPLY WITH ALL SAFETY PRECAUTIONS. Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shut down and lock out this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment.	1	All			Т
		THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED. When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner or a damp rag must be used in place of compressed or blown air. A lint-free cloth or brush may be used on optical equipment only when other cleaning methods cannot be used. Report safety deficiencies to your supervisor immediately upon detection.					
		WARNING FOR EWP/PPE: Steps contained in this bulletin may require the use of Personal Protective Equipment (PPE). Refer to the current Electrical Work Plan (EWP) MMO for appropriate PPE and barricade requirements.					
CIOSS OPM: MACHINE LOG	2.	At the beginning of the operation examine machine log. WARNING Be cautious when working around or on equipment when power has been applied. This task requires that the machine be running. Take precautions to prevent hair, clothing, jewelry, tools, and test equipment from being caught in moving parts. NOTE While performing listed operational maintenance tasks, be alert for unusual sounds, odors, or other indications of potential failure conditions in the machine.	1	9			T

U.S. Postal Service		IDENTIFICATION														
Maintenance Checklist	WC CO		EQUIPMENT ACRONYM								CLA CO	N	UMBE	TYPE		
	0	9	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature	Equi	ipmer	nt Mo	del				В	ulletin I			1	Occurr			
Combined Input Output Sub- System									M	M1	4121			I	our	

System							
Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Thresholds	3
·			Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
		Examine log and document any unresolved problems from the previous tour.					
		NOTE					
		Operational checks must be made with machine processing mail in a normal operating mode.					
CIOSS OPM: SYSTEM SAFETY INDICATORS	3.	Every two hours check warning horn and beacons.	1	9			Т
		Watch for proper operation of warning horns and beacons on start-ups.					
CIOSS OPM:	4.	Every two hours check lamps.	1	9			Т
MACHINE INDICATOR LAMPS		Watch for proper functionality of indicator lamps used during normal machine operations. Correct deficiencies as soon as practical.					
CIOSS OPM: OPERATORS	5.	Every two hours observe feeder. Observe the Feeder operation and inquire if operators are having excessive processing problems. Investigate as necessary. Initiate corrective action as appropriate.	1	9			Т
CIOSS OPM: WFOV CAMERAS	6.	Every two hours check the On Line Mail Processing screen. WARNING Use caution when working around WFOV aperture. Edges of aperture may become extremely sharp during machine use. If MAR or GAR is below acceptable values: 1. Check for degraded image and/or dust/debris accumulations on WFOV faceplate by observing the thumbnail image on the upper left on the GUI. 2. If the image is degraded or if problems are noted take appropriate corrective action.	1	9			T

U.S. Postal Service								IDE	NTIF	CAT	ION					
Maintenance Checklist	_	RK DE								CLASS CODE				IUMB	TYPE	
	0	9	С	ı	0	S	S				Α	В	0	0	1	М
Equipment Nomenclature Combined Input Output Sub- System	Equi	ipmer	nt Mo	del				В	ulletin N		name 4121		Occu	rence	Γour	

System							
Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Thresholds	;
·			Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
CIOSS OPM: READERS, ICS-3 (3 READERS)	7.	 Check ICS-3 ID tag reader's exterior for accumulated dust, dirt and debris or loose/worn belts, paying particular attention to the aperture and to the raised portion of the faceplate. Document any problems found, and if needed write a work order. 	3	9			Т
CIOSS OPM: IMAJE INK JET PRINTER, POSTNET	8.	Every two hours check for dirt/ink accumulations. Check POSTNET Ink Jet Printer to ensure there is no build-up of foreign material or accumulation of ink at the print head. Document any problems found, and if needed write a work order.	2	9			Т
CIOSS OPM: IMAJE INK JET PRINTER, ID TAG	9.	Every two hours check for dirt/ink accumulations. Check ID Tag Ink Jet Printer to ensure there is no build-up of foreign material or accumulation of ink at the print head. Document any problems found, and if needed write a work order.	2	9			T
CIOSS OPM: HSLA (BOTH)	10.	Every three hours check for dirt accumulations. Check and remove debris from the HSLA 1 and HSLA 2 areas. Wipe application drum.	2	9			Т
CIOSS OPM: POSTJET ADDRESS LABEL PRINTER	11.	Every two hours check for quality of print. When on this operation check the quality and readability of the labels being applied. Document any problems found, and if needed write a work order.	2	9			Т
CIOSS OPM: BAR CODES	12.	Every two hours check bar code printing. Check for print quality of POSTNET and ID Tag bar codes. Document any problems found and if needed write a work order. If further analysis is needed refer to an Electronic Technician.	1	9			Т

U.S. Postal Service								IDEI	NTIFIC	CATI	ION						
Maintenance Checklist		RK DE					MENT DNYM		CLASS CODE					NU	TYPE		
	0	9	С	I	0	S	S				Α	В	()	0	1	М
Equipment Nomenclature	Equ	ipmer	nt Mo	del				Вι	ılletin l	Filer	name		Occi	ırre	ence		
Combined Input Output Sub-									M	M1	4121				Т	our	
System																	

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill	Thresholds					
		(comply man all canonicality probability)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.			
CIOSS OPM: SORTING	13.	Every two hours check for missorts.	2	9			Т			
STACKERS		Take a sample from at least 5 stackers and verify the address block matches the scheme for that pocket. Verify mail pieces enter stacker in a uniform manner. Document any problems found and if needed write a work order.								
CIOSS OPM: OVERFLOW		Every two hours check mail in the Overflow/Reject Stacker.	2	9			Т			
STACKER		Check type of mail present in overflow stacker to determine which area(s) of the machine might be malfunctioning. Check for indications of double feeds, one particular code, a single gate, or mail path blockage problem. Document any problems found and if needed write a work order.								
CIOSS OPM: ACE/MKAT LAPTOP COMPUTER		Every 2 hours check all performance indicators displayed on the MPEWatch Realtime Maintenance View Screen including the following items:	5	9			Т			
		Key Performance Indicators (KPI) report.								
		NOTE								
		Access to KPI can be done by clicking on the hyperlink located in the column titled "KPI%".								
		2. Unplanned Events.								
		3. DPS Information.								
		 Take appropriate action to investigate and correct any abnormalities detected in viewing MPEWatch. Generate a work order for further maintenance actions if required. 								
CIOSS OPM: ADMINISTRATIVE		At the end of the operation tour, compile the following information:	2	9			Т			
		Route sheet information.								
		Any work orders generated.								
		Make entries in Machine Logbook of any discrepancies found during the mail run.								
		Turn this information into Maintenance Supervision. Brief personnel coming on duty.								